



MANDATORY SERVICE BULLETIN

No. MSB-E4-022/3
SUPERSEDES MSB-E4-022/2

1. BASIC INFORMATION

1.1. SUBJECT

Waste Gate Control Rod.

1.2. ENGINES AFFECTED

Engine type: E4
Engine model(s): E4, E4P
Serial number(s): all

1.3. REASON

Waste gate control rods with insufficient fatigue life have been identified. Failure of the waste gate control rod will lead to a partial loss of power.

As precautionary action Austro Engine prescribes a time limit for the waste gate controllers without waste gate con-rod fail-safe bridge.

As terminating action for the time limit the waste-gate control-rod fail-safe bridge has been introduced. After installation of the waste-gate control-rod fail-safe bridge the waste-gate controller is set on condition with specified scheduled maintenance checks per Maintenance Manual.

1.4. TIME OF COMPLIANCE

Initial action:

- Upon reaching 250 flight hours in service time of the waste gate controller
- For E4-B and E4-C engines installed on DA 42 M-NG with external containers and E4-A engines:
For waste-gate controllers with more than 200 flight hours as of 27-Nov-2017 within the next 50 flight hours, but not later than 28-Feb-2018 if 250 flight hours in service time of the waste gate controller are exceeded as of 28-Feb-2018.
- All other engines:
For waste-gate controllers with more than 200 flight hours as of 27-Nov-2017 within the next 100 flight hours, but not later than 31-May-2018 if 250 flight hours in service time of the waste gate controller are exceeded as of 31-May-2018.

First Issue Date			Rev. No.	Revision Date			Page
02	Nov	2017	03	16	Apr	2018	1-5



Mandatory Service Bulletin
No. MSB-E4-022/3

Austro Engine GmbH
Rudolf-Diesel-Strasse 11
2700 Wiener Neustadt
PHONE: +43 2622 23000
FAX: +43 2622 23000-2711

Repetitive Action:

- Upon reaching 250 flight hours in service time of the waste gate controller

Terminating Action:

- Within 200 flight hours after 30-Apr-2018, but not later than 31-Oct-2018

Prior compliance with MSB-E4-022 through MSB-E4-022/2 is considered equivalent to the initial action or repetitive action, as applicable.

1.5. CONCURRENT DOCUMENTS / REFERENCES

- Maintenance Manual E4 Series – Doc. No.: E4.08.04, latest effective issue

1.6. OTHER PUBLICATIONS AFFECTED

None.

2. TECHNICAL DETAILS

2.1. ACCOMPLISHMENT / INSTRUCTIONS

Initial Action:

1. Make sure MM-TR-MDC-E4-386 and MM-TR-MDC-E4-399 are inserted into the Maintenance Manual or a revision of the Maintenance Manual with the Temporary Revisions incorporated is used.
2. Replace the waste gate controller according to Maintenance Manual section 81-00-33.
3. Install a new the spring loaded circlip E4A-41-100-801. Refer to figure 4

Repetitive Action:

1. Replace the waste gate controller according to Maintenance Manual section 81-00-33.
2. Install a new the spring loaded circlip E4A-41-100-801. Refer to figure 4.

First Issue Date			Rev. No.	Revision Date			Page
02	Nov	2017	03	16	Apr	2018	2-5

Terminating Action:

1. Make sure MM-TR-MDC-E4-422 is inserted into the Maintenance Manual or a revision of the Maintenance Manual with the Temporary Revisions incorporated is used.
2. If not yet installed, install a new spring loaded circlip E4A-41-100-801. Refer to figure 4.
3. Install the waste-gate con-rod fail-safe bridge according to Maintenance Manual section 81-00-36 or install a waste-gate controller with the fail-safe con-rod bridge already installed. Make sure there is sufficient clearance to adjacent parts.




Figure 4: Waste Gate Circlip

2.2. MASS (WEIGHT)

Negligible.

2.3. APPROVAL STATEMENT

The technical content of this document has been approved under the authority of DOA No. EASA.21J.399.

First Issue Date			Rev. No.	Revision Date		Page	
02	Nov	2017	03	16	Apr	2018	3-5



3. PLANNING INFORMATION

3.1. MATERIAL & AVAILABILITY

For replacement of the waste-gate controller:

Qty	Part Number	Description
1	E4A-41-120-000	Waste Gate Controller
1	E4A-41-100-801	Spring loaded circlip

For the terminating action:

Qty	Part Number	Description
1	E4A-41-100-801	Spring loaded circlip (if not yet installed)
1	AEP-00265-100	Bracket Assy 1
1	AEP-00265-100	Bracket Assy 2
2	AEP-00247-801	Screw with drill hole
2	E4A-53-300-801	Screw with drill hole

3.2. SPECIAL TOOLS

As stated in the Maintenance Manual E4.08.04.

3.3. LABOR EFFORT

0.5 hours.

First Issue Date			Rev. No.	Revision Date			Page
02	Nov	2017	03	16	Apr	2018	4-5



4. REMARKS

NOTE:

- All measures must be carried out by a certified engine station and certified engine mechanics.
- The accomplishment of the instructions shown under chapter 2.1 must be confirmed in the respective engine log book.
- The accomplishment of the instructions must be carried out within the time of compliance according chapter 1.
- In case of doubt please contact the Austro Engine GmbH – After Sales Support (e-mail: service@austroengine.at; Tel: +43 2622 23000 2525).
- For credit information contact Austro Engine GmbH – After Sales Support (e-mail: service@austroengine.at; Tel: +43 2622 23000 2525)

5. EXPLANATORY NOTES

5.1. SYMBOL EXPLANATION



WARNING: Disregarding these safety rules can cause personal injury or even death



CAUTION: Disregarding these special instructions and safety measures can cause damage to the engine or other components.



NOTE: Additional note or instruction for better understanding of an instruction

First Issue Date			Rev. No.	Revision Date			Page
02	Nov	2017	03	16	Apr	2018	5-5